

Firescreen Front for the 6000 Series

- Installation Instructions -

⚠ CAUTION: Glass is HOT during operation and cool down.

These instructions are to be left with a person responsible for the use and operation of the fireplace.

This door is supplied from the factory with an ON/OFF Wall Switch. See instructions in the wall switch kit for installation of wall switch.

⚠ WARNING: ALWAYS BE SURE FIREPLACE IS OFF AND COOL BEFORE HANDLING DOORS.

Installation

Note: Keep in mind the doors are HOT while in operation.

1. Remove any existing door from fireplace.
2. Remove any packaging from the door.
3. Hang door on fireplace by inserting hooks on sides into slots on each side of glass.

Interchangeable Decorative Panels

1. The decorative panel at the bottom of this door is interchangeable with many different options.
2. To replace these panels remove door from the unit. On the back of the door, remove the two 3/8" nuts on each panel (see Figure 1). Remove the panel from the bolts.
3. Slide the mesh out of the panel and place it in the new panel. Place the new panel onto the bolts and secure with the nuts.



Figure 1

Service Replacement Parts

REPLACEMENT PARTS	UNITS	
	DF-6-FS-PT	DF-6-FS-BK
Left Top Curl Assembly	383-134A	383-134A
Right Top Curl Assembly	383-135A	383-135A
Left Bottom Curl Assembly	383-136A	383-136A
Right Bottom Curl Assembly	383-137A	383-137A
Access Panel Assembly	383-201A	383-201A
Mesh Panel	383-146	383-146
Mesh	383-330A	383-330A